


ELD Visor Card

NOTE: Please always keep this in your truck in the event of a roadside inspection.

Navigate the RAND ELD App

The Home screen is the first screen you login, select your asset, and connect to your ECM device




Inspection Mode: Transfer Your Logs to Law Enforcement

During a roadside inspection, you can transfer your logs to a Law Enforcement Officer (LEO). When you enter Inspection Mode, the LEO can view all your logs for the past 7 (US) or 14 (Canada) days. You must enter your password to exit this mode. You also have the option of emailing your logs instead.

From the **Home** screen, tap the **Inspection Mode** icon.

Transfer Logs

- Initiate transfer of logs
 - Select **EXPORT ELD OUTPUT FILE**
 - Select data transfer mechanism identified by the LEO
 - Enter File Comment provided by the LEO
 - For email transfer, enter the email address provided by the LEO.
- Select the back button on your device to exit Inspection Mode.
- On the **Password** screen, enter your password and tap OK to exit Inspection Mode.
- Additional information can be found in the **HELP and SUPPORT** section of the app under **IN-CAB REQUIRED DOCUMENTS**.




Inspection Mode: Show Your Logs

From the **Home** screen, tap the **Inspection Mode** icon.

Display Logs

- 1. Display your logs to a LEO
 - Select **PRINT-DISPLAY LOGS**
 - Select PDF View
 - Enter File Comment
 - Select **SAVE**
 - PDF of logs will open
 - If the logs do not automatically open, review your devices downloaded files.
- 2. Select the back button on your device to exit Inspection Mode.
- 3. On the **Password** screen, enter your password and tap **OK** to exit Inspection Mode.
- 4. Additional information can be found in the **HELP and SUPPORT** section of the app.




Malfunction Indicators

- 1. On the Home screen, the data diagnostic and malfunction events indicators are shown.
- 2. Indicator lamps will display green when there are no diagnostic or malfunction events. Otherwise, they will display red.
- 3. Tap on **Data diagnostic** to view the active data diagnostic or tap on **Malfunction** to view the active malfunctions when the indicator lamp is red.

Malfunction Driver Action

- 1. For all data diagnostic and malfunctions, ensure the ECM device is connected to your device.
- 2. From the **MAIN MENU**, select the **DIAGNOSTIC** option to verify the app is receiving all required data.
- 3. If all data is being received and no active Data Diagnostics are occurring, the malfunction should automatically clear itself within 24 hours.
- 4. Ongoing malfunctions must be reported to your motor carrier within 24 hours of occurring to allow adequate time to fix the issue.
- 5. Additional information can be found in the **HELP and SUPPORT** section of the app under **IN-CAB REQUIRED DOCUMENTS**.





WARNING

Never attend to the device or allow it to distract you while driving. Failure to pay full attention to the operation of your vehicle could result in death, serious injury or property damage.

NOTE: Screenshots used in this card are portrait orientation; the same functionality applies when the screen used is landscape.

For device malfunction and customer support, call **1-800-641-7263**.

©2023 Rand McNally. All rights reserved. The information contained herein is subject to change without notice. Rand McNally endeavors to ensure that the information in this document is correct and accurately stated, but Rand McNally is not liable for any errors or omissions. Published information may not be up to date, and it is important to confirm status with Rand McNally. HOS requirements are subject to regulatory and statutory revisions and modifications. The technical data may be subject to U.S. and international export, re-export, or transfer (export) laws. Diversion contrary to U.S. and international law is prohibited.